

WT-9002 IP65


**GSM Intercom
And
Access Control System**

User Manual






INSTALLATION & WIRING DIAGRAM



Note: The call point must connect to the main unit with cables that are not exceeding 15 meters to avoid poor voice quality.



Inputs and Outputs Wiring Connections

CONTENTS

1.	Introduction.....	5
2.	WT-9002 IP65 Features.....	5
3.	Installation Instruction.....	7
4.	WT-9002 IP65 Programming Instructions.....	8
4.1	Description.....	9
4.2	Programming the Administrator Numbers via Phone Call.....	11
4.3	Programming the Administrator Numbers via SMS.....	12
4.4	Read the Programmed Administrator Numbers via SMS.....	13
4.5	Changing the Password via Phone Call.....	13
4.6	Changing the Password via SMS.....	14
4.7	Changing the Administrator Numbers via Phone Call.....	14
4.8	Changing the Administrator Numbers via SMS	15
4.9	Disconnecting the call via the handset.....	16
4.10	Programming the Guest List via Phone Call.....	16
4.11	Programming the Guest List via SMS.....	17
4.12	Programming the Guest List via Learning Mode.....	18
4.13	Remove Guest Number from the List.....	19
4.14	Restore deleted Guest Number.....	21
4.15	Relay Function.....	21
4.16	Activate relays via SMS.....	22
4.17	Extending latching time of relays via SMS.....	22
4.18	Temporary latches the relays via Phone Call.....	23
4.19	Temporary latches the relays via SMS.....	24
4.20	Latches the Relays to Stay ON.....	25
4.21	Displays Programmed Administrator Number.....	26
4.22	Access Control for Administrator and User.....	26
4.23	Turn ON/OFF SMS Report from the Unit.....	26
4.24	Checking Signal Strength.....	27
4.25	AC Power ON/OFF Alert Messaging.....	28
4.26	Adjusting the Speaker volume of Intercom.....	28
4.27	Adjusting the Microphone volume of Intercom.....	28
4.28	Turn ON/OFF the Sound of Alarm when Main Power Off.....	29
4.29	Setting the Alarm Time Value.....	29
4.30	Checking the system is operating correctly.....	30
4.31	Resetting the Unit.....	30
4.32	Setting the Output Relays to Supply Voltage or Dry Contact when activated.....	30
5.	Functions Summary.....	32
6.	Technical Specifications.....	33

PACKAGE CONTENTS

- 1) 1 pc IP65 Enclosure
- 2) 1 pc WT-9002 Main Board with GSM Module mounted
- 3) 1 pc Stainless Steel Call Point
- 4) 1 pc Power Adapter
- 5) 1 pc Battery Backup
- 6) 1 pc GSM Antenna
- 7) 1 pc LCD Display for Assisting in Programming

1. INTRODUCTION

GSM Intercom - The WT 9002 is the GSM Intercom in front of your gate that includes a speaker, microphone and "call" push button. When visitor at the gate presses the doorbell, the system will call to the house owner mobile phone if he is not at home. The owner can speak to the visitor and open the gate by simply pressing the passwords on his mobile phone

GSM Access Control - The WT 9002 also is the access control system. You can register up to 1,000 users in the system if any of the users call to the gate automation system, it allows to open your gate with your mobile phone without any cost. – Absolutely Free Of Charges. You can just simply dial the mobile phone number in the WT 9002 from any phone and the WT 9002 will reject the call and open the gate without any cost. Of course, if not the register user, the door will never open.

GSM Alarm System – The system can connect to motion sensor, Smoke detector, door and window sensors and if any intruder, the alarm system will triggered and it will send the SMS up to 3 mobile phone numbers, instantly alerting you unauthorized entry into the building.

2. WT-9002 IP65 FEATURES

Remote Monitoring Your House & Gate While You Not At Home

WT 9002 is work with 4 wire intercom which will be installed outside the premises or next to the gate as intercom system. When the bell button is pressed, the WT 9002 will dial the number preset inside and inform the owner that visitor at the gate. The owner can answer the call and speak to the visitor and open the gate by entering a pin code from his phone if he wishes to let the guest come in. The system can continue to call 2 consecutive numbers if the first number failed.

Only Register User Can Open the Gate – Up to 1,000 authorized users

When one of the 1,000 register users call to the WT 9002, the system will recognized the caller ID number (phone number) and open the gate automatically.

Put Up A Simple Alarm System While You Not At Home

The system have 2 input can connect to the motion sensor, magnetic door sensor or smoke, gas & glass break sensors. If any intruder or emergency happen, the WT 9002 units will SMS up to 3 telephone number.

Open The Gate Use Your Mobile Phone While You Not At Home

If any visitor in front of your gate and you still not at home, you can open the gate to the visitor by pressing the 6 digit password at your mobile phone and the gate will open to allow the visitor come into the house.

Remote Control to Switch On/Off Lighting, Air Conditional and Any Electrical Appliances

The System has 2 Outputs and you can call in to switch on / off the electrical appliances. For example to switch on the Air Conditional before you enter into the house.

Backup battery to Prevent Power Failure - You House Will Keep Monitoring When Power failure

WT 9002 has a rechargeable battery that powers the system for minimum of 8 hours in the even of a power failure. The battery system will continue to use your utility power until power failure is detected. Once power failure is detected, the battery backup will instantaneously begin to supply and once utility power is restored, the backup will automatically switch off.

Use With Any door bell or Intercom System

WT 9002 will supply together with doorbell. If you dislike the design, you can choose to let the WT 9002 to work with any other Intercom system or doorbell. Just simply connect the 4 wires from WT 9002 to the other manufacturer doorbell system, it will work well.

IP 65 Enclosure


The GSM unit is design fully protected against dust tight and protected against water jets from all directions. It is suitable to use at outdoor and complied to the International IP rating.

3. INSTALLATION INSTRUCTION

Note: It is essential that you read the instructions fully prior to installing and programming the unit

i) INSTALLING THE SIM CARD

Note: Installing the SIM Card. Please be sure the initial 4 digit PIN code of SIM card is disabled. This can be done by placing it in an unlocked Mobile phone and first checking if the SIM requested any PIN code. If this is the case the PIN code can be disabled using the security settings on the phone.



Procedure

1. Slide back the SIM door and lift it up
2. Slide the SIM card into the SIM door making sure that the clipped corner of the SIM card lines up with the clipped corner of the SIM holder
3. Close the SIM door
4. Slide the SIM door to lock the SIM card in place

ii) POWER

The unit can operate with voltage between 12V to 24V AC or DC. Wait 15 seconds for the unit to set up after connecting power. The GSM Status LED will start to flash when the system is ready.

iii) MEMORY

The unit can be programmed up to 1000 phone numbers to become as authorized users. The system will respond or answer to the call of authorized users only and reject unauthorized calls.

iv) OUTPUT

The unit has 2 outputs which can be used as output. The outputs are connected to an on-board relay

v) RELAYS

There are 2 output relays which can be activated by the person called via the keypad on the mobile phone or landline phone. The output relays are both set at factory default to latch for 1 second but can be programmed to latch on for up to 65,535 seconds. The function for Relay 1 is accessible by 1000 programmable authorized users. Relay 2 can only be activated or programmed by the 3 chosen administrator numbers.

vi) OPERATION MODE

The unit can operate in one out of two operation modes: **Automatic** or **Password**

Automatic Mode

If Automatic Mode is chosen (***TEL?#1, *ANY?#1**), the unit will not answer any incoming calls including administrators number and will operate the relay output (Relay 1) automatically.

Password Mode

If Password Mode is chosen (***TEL?#0, *ANY?#0**), the unit will answer any incoming call immediately and indicate it by a short "Beep". The unit will wait for a valid 6 digits pin code to be keyed in by the caller. If the pin code is correct, the caller can access to operate the output relay according to the function chosen. The unit will confirm by one short "Beep" a correct pin code entered and three "Beep" if it is a wrong pin code number.

vii) BACKUP BATTERY

The unit has a rechargeable battery that powers the system for minimum of 8 hours in the event of a power outage. When the power is restored, it will recharge the battery automatically whenever the usage capacity fall below 9V.

4. WT-9002 IP65 PROGRAMMING INSTRUCTIONS


4.1 DESCRIPTION

Note: As the WT-9002 IP65 can only be programmed by the 3 administrator numbers, you must first program those numbers into the unit. Anytime the administrators want to access the system, he/she must enter a 6 digit password.


The system is initially set up using a 6 digit password and this is in the format as follows.

***PAWO#123456** (Factory default)


Once turn on the WT-9002 IP65, the system is setup and you shall see the following



When the system is ready to use, you can see the following




When the system receives the programming message from the administrator, it will display a message icon on the top right corner of the screen as shown below...




After the programming message has been processed, the message icon will disappear

and the system will shows "OK" indicate the setting has changed.




When the system receives a phone call from the administrator, it will display "Admin" on the top and will prompt the administrator to enter password as shown below.



After the administrator enters the correct password, then it will display "Menu". At this state, the administrator is able to access the functions.



When the system receives a phone call, it will display the user numbers and if it is the number from the guest list, it will display "Guest" on the top of the screen. Otherwise, if it is an unknown number the system will display "No Guest" and the call is rejected.



4.2 PROGRAMMING THE ADMINISTRATOR NUMBERS VIA VOICE

The administrator numbers can be program using the following prompts on the keypad and making the following three calls to the unit assuming the following 3 numbers are (1111558888), (2222669999), and (3333770000).

Example:

Once the call has connected... (With a short beep ~ prompt the administrator to enter password, the initial set up password is 123456 by default)

After enter password... (Another short beep ~ Password Correct)

Press ***3#** (you should hear a short beep ~ success)

Continue press **1#** to add the first administrator number (another short beep ~ success)

Then enter the administrator number **1111558888#** (you will hear a short beep ~ the administrator number is setup successfully)

Continue...

Press ***3#** (you should hear a short beep ~ success)

Continue press **2#** to add the second administrator number (another short beep ~ success)

Then enter the administrator number **2222669999#** (you will hear a short beep and the number has been changed to 2222669999)


Continue...


Press ***3#** (you should hear a short beep ~ success)

Continue press **3#** to add the third administrator number (another short beep ~ success)

Then enter the administrator number **3333770000#** (you will hear a short beep and the number has been changed to 3333770000)

If the change has not been successful you will hear 3 beeps and must re-enter again.





4.3 PROGRAMMING THE ADMINISTRATOR NUMBER VIA SMS

The first 3 SMS messages sent to the unit would be as the following assuming the 3 Administration numbers are (1111558888), (2222669999), and (3333770000).

Send the following 3 SMS Commands:

- 1) ***TEL1#1111558888**
- 2) ***TEL2#2222669999**
- 3) ***TEL3#3333770000**

As the first 2 numbers will be the customers own numbers you would program in the Installers number in ***TEL3#**

This number can be changed once the system has been installed.

When the system received the message and the number is programmed successfully, it will display "**OK**" on the screen and the administrator will receive a reply message from the unit.

Example of Return Message:

TEL1=1111558888
TEL2=2222669999
TEL3=3333770000

4.4 READ THE PROGRAMMED ADMINISTRATOR NUMBERS VIA SMS

It is possible to read all the programmed Administrator numbers by sending the following SMS to the unit.

Send the following SMS Commands:

***ADM?#**

Example of Return Message:

TEL1:

1111558888

TEL2:

2222669999

TEL3:

3333770000

END

4.5 CHANGING THE PASSWORD VIA VOICE

The system only allows the 3 administrator numbers as authorized user to change the 6 digits password.

To change the password from the factory default 123456 to 654321 (Example) you can just call the unit and when the unit replies, you can use the following commands using the keypad prompts on your telephone.

Once the call has connected ... (With a short beep ~ prompt the administrator to enter password, the initial set up password is 123456 by default)

After enter password... (Another short beep ~Password Correct)

Press ***2#** (A short beep ~ success)

Then input the current password **123456#** (you should hear a short beep ~success)

Continue to enter new password **654321#** for 2 times (another short beep if password entered correctly)

If the change has not been successful you will hear 3 beeps and must re-enter again.

4.6 CHANGING THE PASSWORD VIA SMS

The system only allows the 3 administrators to change the 6 digits password. To change the password from the factory default 123456 to 654321 (Example) you can just send the following SMS to the unit.

Example:

Sends a SMS Command: ***PAWO#654321**

If the change is successfully, the system will display "OK" on the screen and the administrator will receive a reply message from the unit.

Returned Message:

PAWO-OK

4.7 CHANGING THE ADMINISTRATOR NUMBERS VIA VOICE

It is possible to change any of the administrator numbers using the following prompts on the keypad and making the following three calls to the unit assuming the following 3 numbers are to be changed as.

Example:

Change TEL1 to 4444444444

Change TEL2 to 5555555555

Change TEL3 to 6666666666

Once the call has connected... (With a short beep ~ prompt the administrator to enter password, the initial set up password is 123456 by default)

After enter password... (Another short beep ~ Password Correct)

Press ***3#** (you should hear a short beep ~ success)

Continue press **1#** to change the first administrator number (another short beep ~ success)

Then enter the new administrator number **4444444444#** (you will hear a short beep and the number has been changed to **4444444444**)

Continue...

Press ***3#** (you should hear a short beep ~ success)

Continue press **2#** to change the second administrator number (another short beep ~ success)

Then enter the new administrator number **5555555555#** (you will hear a short beep and the number has been changed to **5555555555**)

Continue...

Press ***3#** (you should hear a short beep ~ success)

Continue press **3#** to change the third administrator number (another short beep ~ success)

Then enter the new administrator number **6666666666#** (you will hear a short beep and the number has been changed to **6666666666**)

If at any time the unit responds with 3 beeps then the number change has been unsuccessful and you must recall the unit and try again!

4.8 CHANGING THE ADMINISTRATOR NUMBERS VIA SMS

It is possible to change any of the administrator numbers by sending a SMS command to the unit assuming the following 3 numbers are to be changed as.

Example:

Change TEL1 to 4444444444

Change TEL2 to 5555555555

Change TEL3 to 6666666666

Simply sends 3 SMS command as below:

- 1) *TEL1#4444444444
- 2) *TEL2#5555555555
- 3) *TEL3#6666666666

The system will replace the current administrator numbers with the new administrator numbers and will reply as follow

Example of Returned Message:

TEL1=4444444444
TEL2=5555555555
TEL3=6666666666

4.9 DISCONNECTING THE CALL VIA THE HANDSET

It is possible to disconnect the call being made from the call point to prevent the network holding the call after hanging up by using the following prompt on the handset whilst the call is active.

Press ***4#** and the call will be disconnected.

4.10 PROGRAMMING THE GUEST LIST VIA VOICE

To program numbers in the list via voice you would use the following prompts once you have called the unit and it has answered assuming you are programming in the following.

Explanation of how it works:

In WT-9002 memory, there are total of 10 lists with list number **0 – 9**. The list number also represents the last digit of a phone number and each list can store up to **100** phone numbers. If the guest number is **222222226**, it will automatically store the number into list number **6**. If the last digit of the guest number is **8**, then it will be stored in list **8**.

Example:

To program **222222226** into the list:

Press ***5#** (A short beep ~ success)

Then you can input the phone number **222222226#** (A short beep ~ success)

And **222222226** is programmed into list 6

Note:

In the display screen of the unit, you should see as below.

<p>Guest:</p>

Continue input the guest number 222222226 and ended with #

<p>Guest: 222222226</p>

And **222222226** is programmed into list 6

4.11 PROGRAMMING THE GUEST LIST VIA SMS

It is possible to program up to 1000 phone numbers to be authorized users in the white list of the unit and this can be done by sending SMS to the unit.

To program up to the 1000 users at this time you have the option of using SMS text.

Example:

To program phone number: 3333333331

Sends SMS command ***BOOK#3333333331**

Hence 3333333331 is programmed into List 1

Returned Message: **BOOK<<3333333331**

For phone number: 2222222225


Sends SMS command ***BOOK#2222222225**

Hence 2222222225 is programmed into List 5


Returned Message: **BOOK<<2222222225**

4.12 PROGRAMMING THE GUEST LIST VIA LEARNING MODE


It is possible to program the 1000 phone numbers into the Guest List via Learning Mode. To do this, you must first supply a 12VDC at Input 1 and turn on the unit as shown below.



Once turn on the WT-9002 IP65, you shall see the following




Now the system is in learning mode. To program a phone number into the list, simply call the WT-9002 unit. When the WT-9002 received the incoming call, it will read the incoming caller ID and automatically program that number into the list. While in learning mode, you have 120 seconds to program a number. Every time the number is read and programmed, the timer will be reset. If there is no programming activity within 120 seconds, the WT-9002 will skip learning mode and proceed to standby mode.



The number has programmed successfully.

Note: If one of the list for example list 1 is full, the new incoming number with last digit number 1 will not program into the list and shall display as the following.



4.13 REMOVE GUEST NUMBER FROM THE LIST

To remove numbers from the list you would send the following SMS assuming you wish to remove the following number from the list.

Example:


To remove a phone number: **666666667**

Simply sends a SMS Command ***DEL>#666666667** to the unit and it will search for number 666666667 in the list and delete it.

Returned Message:

Delete-OK

If repeated guest number is found in the list, it will search and delete the same numbers appear in the list.



To delete all numbers in the Guest List you would send the following SMS to the unit.

Simply sends a SMS Command ***DELB#** to the unit and it will delete all programmed phone numbers in the list.

Returned Message:

Del-Book

To permanently delete all numbers in the Guest List you would send the following SMS to the unit.

Simply sends a SMS Command ***DARE#1** to the unit and it will permanently delete all programmed phone numbers in the list.

Returned Message:


Delete-OK

Warning: If all the numbers have been permanently deleted, it cannot be recovered.

4.14 RESTORE DELETED GUEST NUMBER

It is possible to restore the deleted phone numbers of Guest List and this can be done by sending the following SMS to the unit.

Simply sends a SMS Command ***DARE#0** to the unit and it will restore the deleted phone numbers. In the display screen of the unit, you should see as below.



Returned Message:

Recovery-OK

Note: Phone numbers can be recovered with certain condition which is the number has been deleted with command ***DEL>#** or ***DELB#** only. Certain phone number in the list cannot be recovered with ***DARE#0** if some new numbers were programmed after issuing command ***DEL>#** or ***DELB#**. All phone numbers cannot be recovered if were permanently deleted with command ***DARE#1**.

4.15 RELAY FUNCTION

The output relays are both set at factory default to latch for 1 second.

To activate the 2 output relays during a received call from the Call-Point you would use the following prompts via the telephone hand-set.

Press ***0#** will activate relay 1 for 1 second at factory default.

Press ***1#** will activate relay 2 for 1 second at factory default.

Note: The latch time value can be changed via ***EXT#** command

Relay 1 can also be activated via caller ID from any number that has been programmed in to the authorized user list or the administrators.

Relay 2 can only be activated and controlled by the 3 administrator numbers as programmed in to the unit.

4.16 ACTIVATE RELAYS VIA SMS

It is possible to activate the relays to latch for 1 second at factory default by sending the below SMS command.

Note: The latch time value can be changed via ***EXT#** command

Send the following 2 SMS Command:

- 1) *ECL1#
- 2) *ECL2#

Returned Message:

ECLK1<OK>
ECLK2<OK>

4.17 EXTENDING LATCHING TIME OF RELAYS VIA SMS

It is possible to extend the latching time of both relays for up to the maximum of 65,535 seconds and to change both relay latching times you would send the following SMS command to the unit assuming relay 1 will be 10 seconds and relay 2 will be 60 seconds every time it activates.

Example: Sending the following 2 SMS Command

*EXT1#00010
*EXT2#00060


Example of Returned Message:

EXT1=00010
EXT2=00060


Relay 1 will now latch for 10 seconds every time it is activated (***0#**) via handset, Caller ID or SMS command (***ECL1#**)

Relay 2 will now latch for 60 seconds every time it is activated (***1#**) via handset or SMS command (***ECL2#**)

When relay 1 latches, the unit will display the counter on the LCD as shown.



When both relays latched...



4.18 TEMPORARY LATCHES THE RELAYS VIA PHONE CALL

It is possible to latch both relays for up to the maximum of 65,535 seconds for a certain time. You would use the following prompts assuming relay 1 to be latched for 30 seconds and relay 2 to be latched for 120 seconds

Once the call has connected... (With a short beep ~ prompt the administrator to enter password, the initial set up password is 123456 by default)

After enter password... (Another short beep ~ Password Correct)

Press ***6#** (A short beep ~ success)

Continue press **1#** for relay 1 (A short beep ~ success)

Then input value **00030#** (A short beep ~ success)

Relay 1 will now latch for 30 seconds and after 30 seconds it will switch off and sends a message back to the administrator informed that Relay 1 has closed.

Returned Message:

RLY1-OFF


Press ***6#** (A short beep ~ success)
 Continue press **2#** for relay 2 (A short beep ~ success)
 Then input value **00120#** (A short beep ~ success)

Relay 2 will now latch for 120 seconds and after 120 seconds it will switch off and sends a message back to the administrator informed that Relay 2 has closed.


Returned Message:

RLY2-OFF

When relay 1 latches, the unit will display the counter on the LCD.



When both relays latch...



Note: Anytime if you want to cancel while it latches, you can always call to the unit and set the latching time back to **00000** and it will stops the relay.

If at any time you hear 3 beeps the change has been unsuccessful and you will need to recall the unit and try again.

4.19 TEMPORARY LATCHES THE RELAYS VIA SMS

It is possible to latch both relays for up to the maximum of 65,535 seconds for a certain time. To change both relay latching times by sending the following SMS.

Example:

Temporary latch Relay 1 for 60 seconds
 Temporary latch Relay 2 for 180 seconds

Simply send the 2 SMS command as below:

***RLY1#00060**

***RLY2#00180**

Example of Returned Message:

RELAY1=00060

RELAY2=00180

4.20 LATCHES THE RELAYS TO STAY ON

It is possible to activate the relays to stay on by sending the below SMS command. The relays will stay ON until the switch OFF command is issued.

Send the following 2 SMS Command:

1) ***FRL1#1** – Latch Relay1 to stay ON

2) ***FRL2#1** – Latch Relay2 to stay ON

Returned Message:

FRL1<ON>

FRL2<ON>

Send the following 2 SMS Command to turn OFF:

1) ***FRL1#0** – Switch OFF Relay1

2) ***FRL2#0** – Switch OFF Relay2

Returned Message:

FRL1<OFF>

FRL2<OFF>

4.21 DISPLAY PROGRAMMED ADMINISTRATOR NUMBER

To view the actual admin numbers programmed in you would just call the unit and prompt the following to view all 3 numbers.

Once the call has connected... (With a short beep ~ prompt the administrator to enter password, the initial set up password is 123456 by default)

After enter password... (Another short beep ~Password Correct)

Press ***7#** (beep) and press **1#** and the display will show you number 1 for 10 seconds

Press ***7#** (beep) and press **2#** and the display will show you number 2 for 10 seconds

Press ***7#** (beep) and press **3#** and the display will show you number 3 for 10 seconds

4.22 ACCESS CONTROL FOR ADMINISTRATOR AND USER

It is possible to control the access of administrator or user to the system by sending the following SMS command to the unit.

Sending SMS Command ***ANY?#1**, the system will allow only the administrators to gain access to the system and the authorized users in this case will not allow to access the system. (**Factory Default: *ANY?#0** ~ Any person can gain access to the system)

Note: It is advised that the owner should set the system to allow access only for administrators after programmed the Administrator numbers.

Sending SMS Command ***TEL?#1**, the system will **Not** receive phone call from both administrators and users but will activate relay 1 immediately. (**Factory Default: *TEL?#0** ~ able to receive phone call only from administrator but will not activate relay 1 immediately)

4.23 TURN ON/OFF SMS REPORT FROM THE UNIT

It is possible to turn ON/OFF the request of report message when inputs triggered from the unit by sending the following SMS command to the unit.

Example of sending the below command:

***RERN#100** (Factory Default)

Only Administrator number **1#** will receive a report message after setup

Returned Message:

RERN:<100>

***RERN#110**

Administrator number **1#** and **2#** will receive a report message after setup

Returned Message:

RERN:<110>

***RERN#111**

All the Administrators will receive a report message after setup

Returned Message:

RERN:<111>

Sending the below command will turn Off this feature:

***RERN#000**

4.24 CHECKING SIGNAL STRENGTH

To check the signal strength (0-31), you would send the following SMS command to the unit.

***CSQ?#**

Example of Returned Message:

CSQ=<27>

4.25 AC POWER ON/OFF ALERT MESSAGING

The unit is able to send alert message to the administrator in the event the main power is out / turned off. When the main power is restored it can notify the administrator again the main power is on.

When main power **OFF**

The unit will send a message: **ACP-OFF**

Note: At the same time, it will send an ALWAYS high pulse out from I/O port. Alarm will sound.

When main power restored

The unit will send a message: **ACP-ON**

4.26 ADJUSTING THE SPEAKER VOLUME OF INTERCOM

It is possible to adjust the speaker volume (from level 0 to 6) of the intercom by sending the following SMS command. **Factory Default: 4**

Example: Sending the following SMS Command

***SOUD#5** – Adjust the volume to 5

Example of Returned Message:

SOUND:<5>

4.27 ADJUSTING THE MICROPHONE VOLUME OF INTERCOM

It is possible to adjust the microphone volume (from level 0 to 9) of the intercom by sending the following SMS command. **Factory Default: 2**

Example: Sending the following SMS Command

***MICO#5** – Adjust the volume to 5

Example of Returned Message:

MICO:<5>

4.28 TURN ON/OFF THE SOUND OF ALARM WHEN MAIN POWER OFF

It is possible to turn on/off the sound of alarm when main powers off by sending the following SMS command to the unit.

Sending the below command will turn **On** the function:

*ALAC#1

Returned Message:

ALAC-ON

Sending the below command will turn **Off** the function:

*ALAC#0

Returned Message:

ALAC-OFF

4.29 SETTING THE ALARM TIME VALUE

It is possible to set the alarm time up to maximum value of 65535 seconds by sending the following SMS command to the unit. (**Default Value: 600**)

Example sending the following SMS Command:

*ALTM#00060 – The alarm will sound for 60 seconds every time it triggered

Example of Returned Message:

ALTM:<00060>

4.30 CHECKING THE SYSTEM IS OPERATING CORRECTLY

It is possible to check the system is operating correctly by sending the following SMS command to the unit.

Send the following SMS Command:

***TEST#**

When the unit replies **TEST-OK** indicate the unit is operating correctly.

Note: If you receive no reply then unit is not working

4.31 RESET THE UNIT

To reset the unit, you can send the following SMS command to the unit.

Text Command:

***REST#XXXXXX**


XXXXXX stands for 6 digits password based on ***PAWO#** (Default: **123456**) and it can be changed anytime.

Warning: User can use their preset password to reset the unit and it must be noted down or remembered. In case if the password is forgotten or cannot be accessed, please consult our technical department.


To manually reset the unit, you can press and hold on the "Call" button and turn on the unit for 10 seconds. The unit will displays **Wait...** and then **OK**, the unit is reset.

4.32 SETTING THE OUTPUT RELAYS TO SUPPLY VOLTAGE OR DRY CONTACT WHEN ACTIVATED

To set the output relays to supply DC voltage (Based on the power adapter used) when activated, please adjust the jumper according to the below diagram.



To set the output relays to dry contact when activated, please adjust the jumper according to the below diagram



5. FUNCTIONS SUMMARY

Functions of WT-9002 IP65 (Via Phone Call)

- | | |
|-------------------------------------------------|-----------------------------------------------------|
| 1) Activates Relay 1
*0# | 5) Disconnecting the call via the handset
*4# |
| 2) Activates Relay 2
*1# | 6) Programming the Authorized User List
*5# |
| 3) Changing the Password
*2# | 7) Temporary latch the relays
*6# |
| 4) Programming the Administrator Numbers
*3# | 8) Displays Programmed Administrator Numbers
*7# |

Functions of WT-9002 IP65 (Via SMS)

- | | |
|--------------------------------------------------------------------------------|-------------------------------------------------------------------|
| 1) Programming the Administrator Numbers via SMS
*TEL1#
*TEL2#
*TEL3# | 11) Access Control for Administrator and User
*ANY?#
*TEL?# |
| 2) Read the Programmed Administrator Numbers via SMS
*ADM?# | 12) Turn ON/OFF SMS Report from the Unit
*RERN# |
| 3) Changing the Password via SMS
*PAWO# | 13) Checking Signal Strength
*CSQ?# |
| 4) Programming the Guest List via SMS
*BOOK# | 14) Adjusting the Speaker volume of Intercom
*SOUD# |
| 5) Remove Guest Number from the List
*DEL>#
*DELB#
*DARE#1 | 15) Adjusting the Microphone volume of Intercom
*MICO# |
| 6) Restore Deleted Guest Number
*DARE#0 | 16) Turn ON/OFF the Sound of Alarm when Main Power Off
*ALAC# |
| 7) Activate relays via SMS
*ECL1#
*ECL2# | 17) Setting the Alarm Time Value
*ALTM# |
| 8) Extending latching time of relays via SMS
*EXT1#
*EXT2# | 18) Checking the system is operating correctly
*TEST# |
| 9) Temporary latch the relays via SMS
*RLY1#
*RLY2# | 19) Resetting the Unit
*REST# |
| 10) Latches the Relays to Stay ON
*FRL1#
*FRL2# | |

6. TECHNICAL SPECIFICATIONS

- Built in power supply 15 Volts 1 Amps and fused 2 amps.
- Quad Band Module (850/900/1800/1900Mhz)
- Power Supply: 100VAC ~ 250VAC
- Operating Temperature - 25 to 55°C
- Humidity Less than 95% RH.
- Lightning Protector: 3-5W
- 2 Output relays normally open 240 volts 1 amp.
- Can call up to 3 numbers outbound.
- Battery back-up for up to 8 hours.
- Caller ID for up to 1000 users.
- Connections for manual operation of both output relays.
- Programmable via S.M.S or Voice.
- Optional LCD for site programming and diagnostic status of system.
- Facility to switch off modem and retain hard wired Intercom if applicable.
- Comes in IP 65 enclosure with external flange mounting.
- C.E Approval

WARRANTY

Witura Corporation Sdn Bhd warrants all WT-9002 GSM Access Control System against defective parts and workmanship for 1 year. Witura Corporation Sdn Bhd shall, at its option, repair or replace the defective equipment upon the return of such equipment to any Witura branch. This warranty applies ONLY to defects in components and workman-ship and NOT to damage due to causes beyond the control of Witura, such as incorrect voltage, lightning damage, mechanical shock, water damage, fire damage, or damage arising out of abuse and improper application of the equipment.

Note: Wherever possible, return only the PCB to Witura Service Centres.
DO NOT return the enclosure.

The WT-9002 IP65 is a product of
Witura Corporation Sdn Bhd
And is Manufactured by
Shenzhen Witura Telecommunications Co., Ltd.

WARNING

For safety reasons, only connect equipment with a telecommunications compliance label. This includes customer equipment previously labelled permitted or certified.